

Courtenay Sport – Balancer Shaft Deletion Kit Additional Fitting Instructions.

This operation should be completed once the balancer shafts have been removed and prior to the installation of the balancer shaft deletion kit.

To block off the oil feeds to the balancer shafts:

Remove bearing caps, where indicated below.

Drill Four 6.8mm diameter holes to a depth of 11.0mm where indicated in the picture below.

Tap thread M8 x 1.25

Fit grub screws with thread locking compound and tighten fully home.

Finally peen over the edge of the hole for extra security.

